







CAUTION:

Stay clear of pontoon and all moving parts while Ultra Legs® are in use. NEVER swim or walk underneath pontoon at any time. Failure to do so may result in serious injury or death. Ensure adequate space is had before adjusting the pontoon position in any way.

Remote Control Operation:

- ALL  : Extends all legs together, raising the boat.
- ALL  : Retracts both legs together, lowering the boat.
- FRONT  : Extends legs at the front of the boat, lifting the bow.
- FRONT  : Retracts legs at the front of the boat, lowering the bow.
- REAR  : Extends legs at the rear of the boat, lifting the stern.
- REAR  : Retracts legs at the rear of the boat, lowering the stern.

Note: Ultra Legs® may be operated without the remote via toggle switches located with the Power Unit, generally located inside a rear seat compartment.

Program Remote:

Ultra Leg remote receivers allow for the programming of up to three (3) remote control units. To program a new remote control or to reset the original remote control if the remote receiver no longer recognizes it, follow the following instructions.

1. Locate the remote receiver in the compartment next to the hydraulic pump.
2. Disconnect the harness from between the pump and receiver.
3. Reconnect the harness between the pump and receiver. The receiver will now be in "Pairing Mode" for 10 seconds.
4. Press and hold ON button on the remote for three (3) seconds during the pairing window.
5. The remote should now function properly.

Remote Troubleshooting:

1. Each remote is equipped with a 10-minute standby timer. After 10 minutes of no commands being sent, the remote will go into standby mode. To resume operation, press the ON button to wake the remote and resume control. Toggle switches will remain operational on the receiver box even if the remote is in standby mode.
2. The receiver can hold up to three (3) remote pairings. Pairing a new remote after all three pairings are filled will cycle and remove the oldest stored remote to add the newest pairing.
3. If the pairing process is not able to be completed per the instructions, ensure the pump is connected to a fully charged battery and that any battery switches are in the "on" position.

General Operating Notes:

- During operation, Ultra Legs® will move the pontoon forward during lifting and backwards during lowering due to the hinging-motion of the legs. Before use, ensure 5'-6' of clearance in front of and behind the pontoon.
- Due to the weight of the engine, the rear legs may lift slower than the front legs. Individual toggle of front and rear legs may be necessary to ensure a level lifting.
- Should the remote control become wet, allow unit to dry before continued operation.
- Replacement remote controls are available through Ultra Legs® should the original be damaged or lost.
- During the leg retract operation, an alarm will activate to notify when each Leg Component has reached full retraction.