

Program Remote:

Ensure the proper operation of your Ultra Legs system time and time again throughout each year by annually following these quick and easy steps.

1. Charge and load test your battery(s) each spring to ensure that it is still strong and capable of operating your Ultra Legs system. A weak battery is the most common cause of issues with the Ultra Legs system.



2. Grease all zerk fittings on the cylinders and pivot points using marine grade grease. Give each fitting about 3-5 pumps of grease or until you can see grease coming out of any openings.



3. Inspect and tighten bolts at pivot points to 10 ft-lb of torque. Do not over tighten!

4. Inspect all footpads for rocks and debris that could be lodged into crevices and cause damage.



5. Inspect each hydraulic hose connection for any visible leaks.



6. Make sure all hoses and wires are still tightly secured under the decking of the boat.



7. Visual inspect the oil reservoir on the pump. The proper level is within 2" from the top. It is mandatory that this is done with the legs fully retracted against the deck.



With these few steps and quick maintenance you can assure another terrific season out on the water with your incredible set of Ultra Legs Pontoon Lifting System.